


Instruction manuals for Three-leg pullerls

(23730, 23731, 23732)



Description:

1. Spindle
2. Puller legs
3. Revolving „nose“

Use:

- a) Assemble the puller arms (2) to download the inner (feet shoulder outward) or external (foot inside shoulders).
- b) Shoulder Pads (2) behind the pulling items and check their tight seating.
- c) Rotary nose screw (3) on the center shaft or hole from which (who) want to download the article (hub, bearing, etc.)
- d) Turn (screw in) screw (1) reasonable force download the required subject.
- e) Ensure that the power puller worked in the axis of the shaft or hole.

IMPORTER: LEVIOR s.r.o.