



LEVIOR s.r.o.  
Troubky č. p. 900  
751 02 Troubky  
CZ 61973939

## **Instructions for use gradient meter**

The gradient meter is used to determine the pitch of the inclined plane.

**Scales of measurement:** - °  
- %  
- vertical alignment

### **Measurement procedure:**

- The body tilt sensor attached to the inclined plane
- Loosen the locking screw scale
- Rotate the disc scale so that the bubble in the level is exactly between the lines vials
- Tighten the locking screw scale
- The chosen scale deducted at the point marked line value of inclination

SUPPLIER: LEVIOR s.r.o.